



Digital 6000

Audinate Brooklyn II (Dante™ interface of EM 6000 DANTE) - Firmware Version 2.1.0.12

Note: Dante firmware is available in two versions: **Device Type 1** (EM 6000 DANTE with one Dante port) and **Device Type 2** (EM 6000 DANTE with two Dante ports).

Features

- ▷ Dante 4.2 support

Firmware update

- The Dante™ firmware update requires Audinate's Firmware Update Manager software: www.audinate.com/products/firmware-update-manager

Previous Releases

Firmware Version 2.0.3.11

- ▷ Maintenance release

Firmware Version 2.0.1.80

- ▷ Dante 4.0 support
- ▷ Support for Through and Redundant modes (for EM 6000 DANTE receivers with two Dante ports)
- ▷ Dante status information is displayed in Menu -> Dante Settings -> Dante Info:
 - Device Type: Dante 1 for device with one Dante port
 - Device Type: Dante 2 for device with two Dante ports
 - Dante network status: OK/Faulty

Firmware Version 1.2.0.23

- ▷ Fix: Issue that the Dante™ output is disabled unintentionally as a result of changes in the word-clock settings.
- ▷ Fix: Issue that the Dante IP address is not updated after changing.