



[www.sennheiser.com/documentation](http://www.sennheiser.com/documentation)



[www.sennheiser.com/download](http://www.sennheiser.com/download)



# MD 445

### Quick Guide

Kurzanleitung

Guide de démarrage rapide

Guida rapida

Instrucciones resumidas

Instruções resumidas

Beknopte gebruiksaanwijzing

Krótká instrukcja obsługi

Snabbguide

Kort vejledning

Pikaohje

Γρήγορος οδηγός

Kisa Kilavuz

Краткая инструкция

快速指南

快速使用指南

クイックガイド

퀵 가이드


Sennheiser electronic SE & Co. KG

Am Labor 1, 30900 Wedemark, Germany  
[www.sennheiser.com](http://www.sennheiser.com)

Publ. 07/26, 583924/A05

## SENNHEISER

### Setup




\*XLR-3 cable not included

### In the box







5 x Pop shield




### Overview

- 1 Sound inlet basket
- 2 XLR-3 connector



## Accessory




\*MZW 5000 not included









MD 445

MZW 5000




## Cleaning



## Specifications

Transducer principle	dynamic
Frequency response	40 - 20,000 Hz
Pick-up pattern	high rejection supercardioid
Sensitivity (free field, at 1 kHz)	1.6 mV/Pa
Dynamic range	145 db (A)
Nominal impedance (at 1 kHz)	245 Ω
Min. terminating impedance	1 kΩ
Connector	XLR-3m
Dimensions	∅ 47.5 x 174 mm
Weight	329 g

## Connector assignment



## Polar pattern and frequency response

